

#### Offering Good Adhesion to Skin

Microfiber Viscose Rayon

# SOFTRAY


SOFTRAY (0.6dtex \*)is one of the finest fibers of regenerated cellulose fibers.


\*Generally the thickness of a human hair is about 56dtex.




### **Adhesive Property**

The finely textured microfiber viscose rayon adheres to the skin.









#### **Smoothness**

Soft feeling to the skin achieved by the microfiber viscose rayon

Test Method: KES method (evaluation of surface characteristics)
Test Laboratory: KAKEN TEST CENTER General Incorporated Foundation
Test Sample: Spunlace nonwoven fabric of 55g/m²

[Note] MMD(fluctuation of frictional coefficient): The lower the measurement value gets, the higher the smoothness becomes and the lower the roughness becomes.




## **Liquid Absorbing Property**

Capillary action of the microfiber viscose rayon improves absorption speed.

Test Method: Compliant with JIS L 1907 Test Method for Water Absorbency(Byreck method)

Test Laboratory: Masuda Mill, Daiwabo Rayon Test Sample: Spunlace nonwoven fabric of 60g/m² weight Test Condition: ①Immerse the lower 5cm of the sample in water

②Leave it for 5minutes and measure the level of water absorbed (repeat twice)





## Daiwabo Rayon Co., Ltd.

Midosuji Daiwa Bldg. 6-8,Kyutaromachi 3-chome,Chuo-ku,Osaka,541-0056,Japan Mail:dr-kanri@daiwaborayon.co.jp FAX:+81-6-7635-3291